REMOTE LINK LAB GUIDE

Instructor-Led Training

DEFAULT INSTALLATION LOCATION

1. Open the Windows File Explorer.
2. Select the **C DRIVE (C:\)**.
3. Locate the **LINK** file and open it.
4. Make sure the DB folder and **LINK.EXE** are located in this folder.

CREATE A PANEL

1. If the **PANEL INFORMATION** window is not open, go to the **FILE** menu and select **PANEL INFORMATION**.
2. In the lower-left corner of the **PANEL INFORMATION** window, click on the **NEW** button.
3. Choose your panel from the drop down list and enter the account number for the panel.
4. Click **OK**.
5. Double-click the panel in the panel information window, or select the panel and click **OK**.
   - The firmware version will update upon first connection

COPY PANEL PROGRAMMING

1. Select the panel you will be copying in the **PANEL INFORMATION** window.
2. Click the **COPY** button.
3. Select the panel model the programming will be copied to and enter the panel account number
4. Click **OK**.
   - If the account number is the same, change the receiver number to avoid duplicates

CONNECT TO A PANEL

1. Select the connection type that will be used in the **TYPE** drop down menu.
2. Enter a **REMOTE KEY** if one is programmed in the panel.
3. Enter the relevant connection information.
   - IP for network, phone number for cell or dialer, COM port and baud rate for direct.
4. Open the panel by clicking the **OK** button or double click the panel in the **PANEL INFORMATION** window.
5. Open the **PANEL** menu and select **CONNECT**.
6. Click the **CONNECT** button.

REVIEW PROGRAM FEATURES

1. Open the **PROGRAM** menu.
2. Program a communication path and a zone.
3. Open the **PANEL** menu.
4. **SEND** and **RETRIEVE** programming
5. **REQUEST EVENTS** from the panel
6. Open **SYSTEM STATUS** window
7. Review the options available in the **SYSTEM STATUS** window
8. Open the **SYSTEM** menu
9. Select **CONFIGURE**, then **REMOTE LINK**
10. Review the different tabs in **REMOTE LINK CONFIGURATION**
    - The Time Zone settings can be found on the Other tab
11. Select **OPERATOR CONFIGURATION**
12. Review settings for Remote Link operators
13. Open the **FILE** menu
14. Review **PRINT** options

REMOTE LINK MODULES

1. Identify the differences between each Remote Link module.
   - Advanced Reporting
   - Alarm Monitoring
   - Account Groups
   - SecureCom Wireless
   - Command Center

QUESTIONS

What else would you like to learn about Remote Link?

NOTES: